

# Ceiling to Floor Cable Fixing Kit Assembly Instructions

Product Code: HA-AC10

## Assembly Tools

- Hexagonal male key 2mm
- Screw
- Alignment instruments
- Screwdriver

## Installation Steps

1. Drill holes on the wall. Screw ② into ① (both top and bottom).
2. Insert the cable into ④, ③ (upwards the screw thread of ④). Clamp ③ (Aluminum Ferrule) to hold the cable. Screw ④ into ① (top).
3. Insert the cable into ⑤, ⑥, ⑦ (downwards the screw thread of ⑤). Screw ⑧ (2 Hex Screws) into ⑦ (cable holder) to hold the cable.
4. Screw ⑤ into ⑨, then ⑨ into ① (bottom).

